

INTERNAL DRY BAG CLIP INSTRUCTIONS

THE MALE CLIP FOR YOUR CARGO FLY TIE DOWN WILL BE FASTENED TO THE CLIP ON THE DRY BAG. UNFASTEN THE MALE CLIP. ON THE INSIDE OF YOUR BOAT TUBE TOWARD THE SECOND SEAT TAB THERE WILL BE A TIE DOWN WITH A PIECE OF WEBBING ATTACHED. TAKE THE MALE FASTEX AND THREAD THE WEBBING THROUGH THE FIRST SLOT THEN THE REST THROUGH THE SECOND SLOT SO THE WEBBING WILL LOCK UNDER PRESSURE. THIS KEEPS THE DRY BAG IN PLACE WHILE BOATING.