

ANKLE CLOSURE FOR TREKKER SUIT

YOU WILL FIND TWO FOAM STRIPS WITH VELCRO IN YOUR SUIT BAG. HOW THIS SYSTEM WORKS IS AS FOLLOWS:

FOR HIKING AND GENERAL USE YOU DO NOT WANT TO USE YOUR BOOTIES. THE PANT CUFFS AS THEY ARE WILL CLOSE DOWN TO A GOOD TIGHT SEAL IF YOU WANT IT TO BE SO, WHICH IS PLENTY ADEQUATE FOR GENERAL HIKING, ETC...WHEN YOU WANT A TRUE DRY SUIT CLOSURE IT IS TIME TO ADD THE BOOTIES AND THE FOAM STRIPS.

PLEASE FOLLOW INSTRUCTIONS:

- 1 PULL UP THE PANT LEG SO YOUR ANKLE AREA IS CLEAR. REMOVE YOUR SHOES BUT NOT YOUR SOCKS.
- 2 WRAP THE FOAM STRIP AROUND YOUR ANKLE. YOU SHOULD WRAP THE STRIP "OVER" YOUR SOCKS. IT WON'T BE TIGHT AND THAT IS FINE, IT CAN JUST "FLOAT" AROUND YOUR ANKLE. THE PURPOSE OF THIS FOAM ANKLET IS TO MAKE A MUCH LARGER SURFACE AREA THAN YOUR ACTUAL ANKLE THAT THE ENLARGED DRY SUIT SEALS CAN MOULD AROUND.
- 3 AFTER THE ANKLET IS IN PLACE, SLIP THE BOOTIE ON AND PULL its LATEX TOP UP OVER THE ANKLET. IT SHOULD REST "ON" THE ANKLET, NOT SLIP OVER THE TOP OF IT. NEXT, PULL THE LATEX SEAL AT THE BOTTOM OF THE PANT LEG OVER THE SAME ANKLET AND THE LATEX TOP OF THE BOOTIE. AFTER BOTH OF THESE SEALS ARE SMOOTH AND IN PLACE WITH A GOOD OVERLAP, PULL THE VELCRO OUTER LEG CLOSURE DOWN OVER BOTH LATEX SEALS AND SNUG THAT CLOSURE DOWN OVER THE TWO LATEX SEALS. THE PRESSURE FROM THE VELCRO CLOSURE LOCKS THOSE TWO SEALS INTO PLACE AND KEEPS THE CLOSURE TOTALLY DRY.

ANKLE CLOSURE FOR TREKKER SUIT

YOU WILL FIND TWO FOAM STRIPS WITH VELCRO IN YOUR SUIT BAG. HOW THIS SYSTEM WORKS IS AS FOLLOWS:

FOR HIKING AND GENERAL USE YOU DO NOT WANT TO USE YOUR BOOTIES. THE PANT CUFFS AS THEY ARE WILL CLOSE DOWN TO A GOOD TIGHT SEAL IF YOU WANT IT TO BE SO, WHICH IS PLENTY ADEQUATE FOR GENERAL HIKING, ETC...WHEN YOU WANT A TRUE DRY SUIT CLOSURE IT IS TIME TO ADD THE BOOTIES AND THE FOAM STRIPS.

PLEASE FOLLOW INSTRUCTIONS:

- 1 PULL UP THE PANT LEG SO YOUR ANKLE AREA IS CLEAR. REMOVE YOUR SHOES BUT NOT YOUR SOCKS.
- 2 WRAP THE FOAM STRIP AROUND YOUR ANKLE. YOU SHOULD WRAP THE STRIP "OVER" YOUR SOCKS. IT WON'T BE TIGHT AND THAT IS FINE, IT CAN JUST "FLOAT" AROUND YOUR ANKLE. THE PURPOSE OF THIS FOAM ANKLET IS TO MAKE A MUCH LARGER SURFACE AREA THAN YOUR ACTUAL ANKLE THAT THE ENLARGED DRY SUIT SEALS CAN MOULD AROUND.
- 3 AFTER THE ANKLET IS IN PLACE, SLIP THE BOOTIE ON AND PULL its LATEX TOP UP OVER THE ANKLET. IT SHOULD REST "ON" THE ANKLET, NOT SLIP OVER THE TOP OF IT. NEXT, PULL THE LATEX SEAL AT THE BOTTOM OF THE PANT LEG OVER THE SAME ANKLET AND THE LATEX TOP OF THE BOOTIE. AFTER BOTH OF THESE SEALS ARE SMOOTH AND IN PLACE WITH A GOOD OVERLAP, PULL THE VELCRO OUTER LEG CLOSURE DOWN OVER BOTH LATEX SEALS AND SNUG THAT CLOSURE DOWN OVER THE TWO LATEX SEALS. THE PRESSURE FROM THE VELCRO CLOSURE LOCKS THOSE TWO SEALS INTO PLACE AND KEEPS THE CLOSURE TOTALLY DRY.